

BRACKETS INSIDE DUCT



PLACE TEMPLATE ON DUCT  
WHERE INSTALLATION IS  
TO BE MADE.

DRILL 8 RED HOLES 1/4"  
CUT OUT SHADED RED RECTANGLE.  
ATTACH PROVIDED BRACKETS TO  
INSIDE OF DUCT AND ATTACH  
OUTER THREADED STUDS WITH  
BLACK THUMBSCREWS.  
MOUNT UVC STERILIZER ONTO  
INNER THREADED STUDS AND  
ATTACH WITH SILVER NUTS.